


Circular Sedimentation (Settling) Tank - Batch Discharges Pumped Discharges - Step 1 - Tank Filling



NOTE: All sediments need to be properly removed and shipped offsite.

Circular Sedimentation (Settling) Tank - Batch Discharges Pumped Discharges - Step 2 - Quiescent (Undisturbed) Settling




START



STOP


One hour
(60 minutes)
of quiescent
(undisturbed)
settling



NOTE: All sediments need to be properly removed and shipped offsite.

Circular Sedimentation (Settling) Tank - Batch Discharges

Pumped Discharges - Step 3 - Pumped Discharge of Clarified Wastewater



NOTE: All sediments need to be properly removed and shipped offsite.